

Release Lock for Gate

With the newest technology that combine safety with locking system, you can easily disengaged the lock system and move the gate freely during power outages.



| | SG-350 | SG-550 |
|-------------------|--|-------------|
| Power Supply | 230V | |
| Power Max. | 40 Watts | 60 Watts |
| Current Max. | 3 Ampere | 6 Ampere |
| Torque Max. | 190 Nm | 290 Nm |
| Operating Voltage | DC13V | DC16V |
| Operating Power | 20 Watts | 30 Watts |
| Operating Current | 1.36 Ampere | 1.65 Ampere |
| Operating Torque | 96 Nm | 140 Nm |
| Output Speed | 2 R.P.M | |
| Opening Time | 10 - 13 second (Total Open/Close) | |
| Keypad Control | 2 wires connection / wireless Open both, left, right wing On / off buzzer On / off auto-close | |








http://www.casa-asia.com

Some changes may have happened to the product after this brochure is printed. The appearance and feature of the actual product may be slightly different from the illustration.

reserves the right to make technical changes to the product without notice.




The Easy Doorway



Autogate Specialist Your One Stop Autogate System Provider

SG-350 Highlight







Features

SG-350 Ideal solution for swing & Foldong gate leaves up to 3m



Enclosure Weather Proof

SG-350 is waterproff and designed to withstand exposure to sunlight.



Backup Battery

Don't worry! Kept running with backup battery during power failures.



Gate Buzzer Alert

3 types of sound buzzer to differential the gate status by wired keypad.



Auto Close Timer

If you worry forgetting to close your gate, then switch on this function where the gate will close by itself after opened for a present time. (with safety beam)



Safety Beam Sensor (optional)

When the gate totally close, the sensor will turn to alarm function. An obstruction to the beam sensor triggers the alarm action, siren will turn on.



While closing, the gate will reverse if there is an obstacle to the motion. Safety Beam Sensor (Optional)

Advance Option

Multifunction Wireless Keypad



- 1. Alarm / Lighting
- 2. Open / Close Both Wings
- 3. Open / Close Left Wing
- 4. Open / Close Right Wing

Wireless Keypad (no buzzer indicator)

Multifunction Wired Keypad



- 1. Panic Alarm / Lighting
- 2. On / Off Buzzer
- 3. Press Open / Close Both Wings

- 4. Press Open / Close Left Wing 5. On / Off Auto-Close 6. Press Open / Close Right Wing

Optional External Lock & SS Bracket



System Lock



By Remote or Keypad